

Manufacturer	Model	Tip Spec.	
<b>Acer</b>	<b>Aspire 1200 Tablet</b> TMC104TCI, TMC110TCi, TMC110Ti, <b>Travelmate</b> TM220, TM230, TM260, TM270, TM279, TM280, TM290, TM350, TM360, TM370, TM520, TM530, TM610, TM620, TM630, TM660, TM100%, TM740, TM800	5.5 *1.7	
	<b>AcerNote</b> 390, 367D, 367T, <b>Anywhere</b> 1100LX, 1120LX, <b>Extensa</b> 365, 390, 393, 900, 366D, 367D, 368D, 390C, Ess3-391T	5.5*2.5	
	<b>Extensa</b> 515, <b>TravelMate</b> 512DX, 512T	5.5*2.5	
	<b>AcerNote</b> 350, 355, 356, 374, 370C, 850C <b>AcerNoteLight</b> 350, 360, 370, 372, 373, 380, 370C, 370P, 370PC, 373+, P100 <b>Extensa</b> 355, 500, 600. 610, 501DX, 501T, 502D, 503DX, 505DX, 506DX, 610CD, 610CDT <b>TravelMate</b> 505DX, 506T, 507DX, 507T, 524TX, 524TXV	5.5*2.1	
<b>AMS Tech</b>	<b>Rodeo</b> 7000, 7620, 1000CT, 1000CX, 1010CT, 1010CX, 1010CXNT, 7030ECX, 7630ECXDNT, 7640XL <b>TravelPro</b> 180, 1900	5.5*2.5	
<b>AVERATEC</b>	3120V, 3150P, 3150H, 3150HS, 3150HX, 5100, 5110H	5.5*2.5	
<b>Compaq</b>	<b>Armada</b> 100, 1100, 1120, 1125, 1130, 4120, 4130, 4131, 4220; <b>LTE</b> 5000, 5150, 5250, 5300, 5380, 5400, 5480, 6000	5.5*2.1	
	<b>Armada</b> 110, E500 Series, E500s, M300, M700, V300; <b>Evo</b> N110, N150, N200, N400c, N410c, N600c, N610c, N620c, N800c, N800v, <b>Presario</b> 300, 2800, 2801, 2802, 2803, 2804, 2805, 2806, 2807, 2809, 2810, 2811, 2812, 2813, 2814, 2815, 2816, 2817, 2818, 2819, 2820, 2821, 2822, 2823, 2825, 2826, 2827, 2828, 2830, 2832, 2835, 2838, 2840, 2845, 2853, 2857, 2858, 2860, 2861, 2862, 286.3, 2864, 2865, 2866, 2867, 2868, 2869, 2870, 2871, 2887, 2888, 2890, 2891, 2892, 2893, 2894, 2895, 2896, 2897, 2898, 2899, 2900, 2902, 2903, 2904, 2905, 2906, 2907, 2908; X1000, X1001; <b>Prosignia</b> 170, 190; <b>Tablet</b> TC1000, NC4000, NC6000, NC8000, NX7000	4.75* 1.7	
	<b>Evo</b> N115, N160, N180; <b>Presario</b> 700, 701, 702, 703, 704, 705, 706, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 100%, 731, 732, 733, 734, 735, 736, 737, 738, 739, 800, 801, 802, 803, 850, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080, 1200, 1201, 1202, 1203, 1205, 1207, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1219, 1220, 1232, 1234, 1235, 1236, 1237, 1238, 1240, 1242, 1244, 1245, 1246, 1247, 1250, 1252, 1255, 1256, 1257, 1260, 1262, 1266, 1267, 1270, 1272, 1273, 1274, 1275, 1277, 1278, 1279, 1400, 1450, 1600, 1610, 1611, 1621, 1622, 1625, 1626, 1645, 1655, 1670, 1680, 1681, 1682, 1685, 1687, 1688, 1690, 1692, 1693, 1694, 1700, 1701, 1702, 1703, 1704, 1705, 1710, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1800, 2700, 2701, 2702, 2710, 2711, 2712, 2715, 2716, 2720, 1600i, 1800t, 12XL, 14XL, 16XL, 17XL, 18XL, 2700xx <b>Prosignia</b> 150	5.5*2.5	
<b>Dell</b>	<b>Inspiron</b> 3000, 3200, 3500, 7000	5.5*2.5	

	<b>LifeBook</b> A1010, C2010, C2110, C2111, C2210, E4010, E4010D, E-6624, E-6634, E-6644, E-6654, E-6664, E7010, E7110,	5.5*2.5	
<b>Fujitsu</b>	<b>LifeBook</b> 200, 270Dx, 280Dx, 400, 420Dx, 435Dx, 500, 531T, 535T, 555Tx, 565Tx, 585Tx, 585Tx1, 600, 635T, 635Tx, 635Tx1 655Tx, 656Tx, 656Tx1, 675Tx, 690Tx, 700, 735Dx, 755TX, 756Dx, 765Tx, 770Tx, 790Tx, 900, 985Tx, 990Tx2, A4170, B2, B112, B142, B2130, B2131, B-2545, B-2562, B-2566, 2610, 2620, 2630, C340, C350, C352, C353, C360, C-4120, C-4235, C-5130, C-5235, C-6177, C-6320, C-6330, C-6525, C-6535, C-6537, C-6547, C-6556, C-6557, C-6577, C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C-7661, Celsius Mobile H, E330, E340, E342, E350, E351, E360, E362, E370, E380, E-2010, E-5140, E-5320, E-5520, E-6150, E-6520, E-6530, E-6540, E-6541, E-6550, E-6555, E-6556, E-6557, E-6570, E-6571, E-6575, E-6595, L440, L470, P-1000, P-1032, P-1035, P-1120, P-2000, P-2040, P-2046, P-2110, P-2120, P-5010, P-5010D, S-2010, S-4510, S-4542, S-5582, S6010, S6110, S6120, S6120D, Stylistic 3400, Stylistic 3500, Stylistic LT C-500, Stylistic LT P-600, Stylistic ST4110, Stylistic ST4110P, Stylistic ST4120, Stylistic ST4120P, Stylistic ST4121, T3010D	6*1	
<b>Gateway</b>	400SD4, 400VTX, 450SX4, 450ROG, 600YG2, 600YGR, M305, M500, <b>Solo</b> 1100, 1150, 1200, 1400, 1450, 2150, 2500, 2550, 3100, 3150, 5150, 5300, 5350, 9100, 9150, 9300 Series, 9500, 9550	5.5*2.5	
<b>HP</b>	<b>Pavilion</b> ZT3010	4.75* 1.7	
	<b>Omnibook</b> 300, 425, 430, 500 510, 530, 600c, 600ct, 900, 900b, xt1000, zt1000, xt1500, 2000, 2100, 2103, 2105, 3000, 3100, 3101, 4000, 4100, xe4100 4101, 4103, 4105, 4150, xe4200, xe4400, xe4500, 5000, 5500, 5700, 6000, xt6050, 6100, vt6200, xt6200, 7100, 7103, 7150, 7103, 7150, VT Series, XE Series, XT Series, XE2 Series, XE3 Series; <b>Pavilion</b> 2105, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3390, N3402, N3410, N3438, N3478, N3490, N5124, N5125, N5130, 5135, 5140, 5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5340, N5341, N5350, N5351, N5371, N5381, N5390, N5402, N5412, N5415, N5420, N5421, N5422, N5425, N5430, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5452, N5454, N 5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N6190, N6195, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, xf125, xf145, xf235, xf255, xf315, xf325, xf328, xf335, xh136, XH156, xh156, xh176, xh215, xh216, xh226, xh355, xh365, xh455, xh485, xh535, xh545, xh555, xh575, xh675, xt115, xt118, xt125, xt128, xt155, xt178, xt183, xt188, xt236, xt276, xt345, xt375, xt395, xt412, xt512, xt537, xt545, xt555, xt565, xt575, xt585, xt595, xu155, xz133, xz148, xz163, xz168, xz185, xz275, xz295, xz335, xz355, ze1000, ze1110, ze1115, ze1145, ze1201, ze1202, ze1210, ze1230, ze1250, ze1260, ze4101, ze4102, ze4103, ze4105, ze4111, ze4115, ze4120, ze4123, ze4125, ze4130, ze4133, ze4140, ze4145, ze4200, ze4201, ze4202, ze4204, ze4206, ze4207, ze4208, ze4209, ze4210, ze4211, ze4214, ze4218, ze4219, ze4220, ze4221, ze4222, ze4224, ze4228, ze4229, ze4230, ze4231, ze4232, ze4234, ze4236, ze4239, ze4240, ze4241, ze4251, ze4258, ze4261, ze4268,	5.5*2.5	

	ze4271, ze4274, ze4278, ze4281, ze4282, ze4284, ze4288, ze4292, ze4294, ze4298, ze4301, ze4305, ze4307, ze4308, ze4310, ze4311, ze4312, ze4313, ze4314, ze4315, ze4316, ze4317, ze4318, ze4319, ze4320, ze4321, ze4323, ze4325, ze4330, ze4332, ze4333, ze4334, ze4335, ze4336, ze4345, ze4347, ze4348, ze4349, ze4351, ze4352, ze4353, ze4354, ze4355, ze4356, ze4357, ze4360, ze4365, ze4367, ze4375, ze4384, ze4385, ze4386, zt1114, zt1120, zt1121, zt1122, zt1125, zt1130, zt1131, zt1132, zt1135, zt1141, zt1142, zt1145, zt1150, zt1151, zt1152, zt1155, zt1161, zt1162, zt1170, zt1171, zt1172, zt1175, zt1180, zt1182, zt1185, zt1190, zt1192, zt1201, zt1210, zt1211, zt1213, zt1230, zt1233, zt1235, zt1243, zt1250, zt1260, zt1261, zt1270, zt1271, zt1290, zt1331, zt3010, zu1155, zu1175		
<b>IBM</b>	<b>ThinkPad</b> 240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 560, 560E, 560X, 560Z, 570, 600, 600E, 600X, 701, 770, 770E, 770ED, 770X, 770Z, A20, A21, A22, A31, i1200, i1300, i1400-2621, i1500-2621. i1720, i1721, R30, R31, R32, R40, T20, T21, T22, T23, T30, T40, T41, TransNote, X20, X21, X22, X23, X31	5.5*2.5	
	<b>ThinkPad</b> 310, 310D, 310E, 310ED 1400-2611, 1500-2611	5.5*2.1	
<b>NEC</b>	<b>LaVie C</b> LC500/4D, LC700/4D, LC700/6D, LC700/7D, LC900/7D, PC-LC3001A, PC-LC3002D, PC-LC5001D, PC-LC5002D, PC-LC5003D, PC-LC5004D, PC-LC5005D, PC-LC5503DW, PC-LC7001D, PC-LC7003D, PC-LC7004D, PC-LC7005D, PC-LC9001D, PC-LC9002D, PC-LC9003E, PC-LC9004D, PC-LC9005D, PC-LC9503E, PC-LC9504E, LC900/4D Series, LC950/4D Series; <b>LaVie F</b> PC-LF5504D, PC-LF5505D, PC-LF7507D, LF550/4D Series; <b>LaVie G</b> PC-LG10JLFEA, PC-LG10JLFEB, PC-LG10JLFJA, PC-LG10JLFB, PC-LG10JSFEA, PC-LG10JSFEB, PC-LG10NRXEA, PC-LG10RRXEB, PC-LG10RRXJB, PC-LG11NRXEB, PC-LG11NRXJB, PC-LG14NFXEC, PC-LG14NRXEC, PC-LG14NRXJC, PC-LG14SSFEB, PC-LG14SSFJB, PC-LG14SSGEB, PC-LG14SSGJB, PC-LG15HLXEC, PC-LG15HLXJC, PC-LG15SEFEC, PC-LG15SEFJC, PC-LG15SSFEC, PC-LG15SSFJC, PC-LG15SSGEC, PC-LG15SSGJC, PC-LG16HEVED, PC-LG16HEVJD, PC-LG16HLFED, PC-LG16HLFJD, PC-LG16HLVED, PC-LG16HLVJD, PC-LG16NFXED, PC-LG16NRXED, PC-LG16NRXJD, PC-LG16SLFED, PC-LG16SLFJD, PC-LG16SLVED, PC-LG16SLVJD, PC-LG16SSUJB, PC-LG18SEFEC, PC-LG18SEFJC, PC-LG18SEVED, PC-LG18SEVJD, PC-LG18SSFED, PC-LG18SSFJD, PC-LG18SSGED, PC-LG18SSGED, PC-LG18SSGJD, PC-LG18SSUJC, PC-LG18SSUJB, PC-LG18SSUJC, PC-LG19NRXEC, PC-LG19NRXJC, PC-LG20NRXED, PC-LG20NRXJD, PC-LG20SEGEC, PC-LC20SEGED, PC-LC20SEGJC, PC-LG20SEGJD, PC-LG20SSUEC, PC-LG20SSUED, PC-LG20SSUJC, PC-LG20SSUJD, PC=LG90RRXEA, PC-LG90RRXJA; <b>LaVie J</b> LJ700/7E, LJ500/4D Series, LJ700/4F Series; <b>LaVie L</b> LL500/6D, LL530/7A, LL550/6D, LL550/7D, LL700/6D, LL700/7D, LL750/7D, LL770/6DT, LL770/7DT, LL900/6D, LL900/7D, LL950/6D, PC-LL3001A, PC-LL3004F, PC-LL5001D, PC-LL5002D, PC-LL5003D, PC-LL5004D, PC-LL5005D, PC-LL5503D, PC-LL5504D, PC-LL5505D, PC-LL7001D, PC-LL7002D, PC-LL7003D, PC-LL7004D, PC-LL7005D, PC-LL100%5D, PC-LL7502D, PC-LL7503D,	5.5*2.5	

	PC-LL7504DW, PC-LL9001D, PC-LL9005D, PC-LL9305D, PC-LL9507D, LL300/4F Series, LL500/4D Series, LL550/4D Series, LL700/4D Series, LL750/4D Series, LL750/4D Series; <b>LaVie M</b> LM500/4E, LM500/7D, LM700/7E; <b>LaVie ME</b> LE500/7D Series; <b>LaVie N</b> LN500/6D, LN500/7D, LN570/7DT; <b>LaVie Pro</b> PC-LH3002A, PC-LH3003F, PC-LH7002D, PC-LH7003E; LaVie T LT500/6D, PC-LT3005D, PC-LT5004D, PC-LT5005D, PC-LT7004D, LT500/4D Series, LT700/4D Series; <b>Pocket Gear</b> MC/PG5000, MC/PG7000 Ready 220T, 230T, 330T, 340T, 360T, 440T; <b>Versa</b> 500, 2400, 2500, 2505, 2530, 4000 Series, 5000, 5060, 5080, 2500CD, 5060CX, 5080X, 550D, C140, C150, C160, E120, E600, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L320, M300, M320, M3210, M500, P440, P520, P600, P700, Premium, S800, T400, T400S820, VersaNote, VX series; <b>VersaPro NX</b> LW23C/52, LW23D, LW26H, LW30H, LW33H		
<b>Panasonic</b>	<b>Toughbook</b> CF01, CF11, CF17, CF170, CF25, CF27, CF270, CF28, CF33, CF34, CF35, CF37, CF370, CF380, CF41, CF45, CF47, CF61, CF62, CF63, CF71, CF-M34, CFV25, CF-V41	6*1	
	<b>Toughbook</b> CF50, CF73, W2	5.5*2.5	
	<b>Toughbook</b> CF-V21, CF-V21P	6*1	
<b>Sharp</b>			
	AV18, AV18P, MC22, MV10W, MV12W, MV14	5.5*2.5	
	MM10, MM20, TN10W, UM10M, UM20, UM30W, UM32W	3.5*1.3	
<b>Sony</b>	<b>Picturebook</b> C1X; <b>VAIO</b> C1MHP, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GP215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, SR1K, SR5K, SR7K, SR9G, SR11K, SR17, SR17K, SR21K, SRX41P, SRX51P, SRX51PA, SRX51PA, SRX51PB, TR1A, TR1AP, TR2A, TR2AP1, TR2AP3, V505A, V505AC, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P7, V505DX, V505DXP, VX71P, Z1, Z1A, Z1A1, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1RA, Z1RAP1, Z1RAP2, Z1RAP3, Z1R5P, Z1SP, Z1VA, Z1VAP1, Z1VAP2, Z1ZAP1, Z505AX, Z505AXP	6*1	
	<b>VAIO</b> 81, 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 812, 818, 838, C1XW, F Series, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, 709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, , FX Series, FX101, FX103, FX105K, FX108K, FX109K, FX120, FX140, FX150, FX170, FX190, FX200, FX201, FX203, FX203K, FX205K, FX209K, FX270, FX 301, FX401, FX405, FX501, FX502, FX505, FX601, FX602, FX604, FX605, FX701, FX702, FX705, FX770K, FX800, FX801, FX802, FX804, FX805, FX880K, FX902P, FX905P, FXA32, FXA33, FXA36, GRS100, GRS150, GRX500, GRS515M, GRS515R, GRS515SP, GR614MP, GRS700, GRX316SP, GRX416SP, GRX516SP, GRX500, GRX520, GRX520/B, GRX550,	6*1	

	GRX560, GRX570, GRX580, GRX590, GRX600, GRX650, GRX670, GRX690, GRX700, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PG32, QR10, QR20, R500, R505CT, R505D, R505DS, R505DSK,R505DT, R505J, R505T, R505TE, R505TEK, R505TS, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK		
<b>Sotec</b>	3120X, 3123XS	5.5*2.5	
<b>Toshiba</b>	<b>Satellite</b> 1000, 1005, 1100, 1200, 1605, 1625, 1675, 1695, 1715, 1100%, 1735, 1750, 1755, 3000, 3005	5.5*2.5	
	<b>Dynabook Satellite</b> 1800, 1850, 1860, 1870, 2140; <b>Dynabook Satellite Pro</b> 440, 460, 480, 490; <b>Dynabook Satellite SS</b> 4000, 3500 Series, S Series, S8 Series; <b>Libretto</b> 60, L Series; <b>Portege</b> R100, M100, M200, 2000, 2010, 3500 Tablet, 3505 Tablet, 4000, 4005, 4010; <b>Satellite</b> A10, A15, M20, M30, M35, 1400, 1405, 1410, 1415, 1555, 1800, 1805, 2060, 2065, 2100, 2105, 2140, 2210, 2250, 2400, 2405, 2410, 2415, 2500, 2505, 2510, 2515, 2530, 2535, 2540, 2545, 2590, 2595, 2615, 2655, 2675, 2695, 2715, 2755, 2775, 2800, 2805, 4000, 4005, 4010, 4020, 4025, 4030, 4060, 4080, 4085, 4090, 4100, 5005, 5105, 5200, 5205; <b>SatellitePro</b> M10, M15, 4200, 4600, 6000, 6100; <b>Tecra</b> A1, M1, M2, S1, 8000, 8100, 8200, 9000, 9100	6.3*3	
<b>Winbook</b>	<b>Winbook</b> J1, N, Si, Si2, X1, X2, X4, XL, XLi, XP, Z	5.5*2.5	
	<b>Winbook</b> FX, XP5 Pro	5.5*2.1	